

Quick Start Guide

16x
MAGNIFY




5 HRS+
BATTERY LIFE



1080 HD
VIDEO



NIGHT
VISION



HIGH
RECOIL



V1

Quick Start Guide

Battery

Positive Facing out

Negative Facing out




Inside V1

Must line up



Inside Cap

Focus/ SD and USB



Focus Adjustment

USB Type C
For external battery use

SD Card Slot

Buttons

POWER

Hold for 5 Seconds to power on

Hold for 3 Seconds to power off

PHOTO/ VIDEO

Single Tap for Photo
Double Tap For Video

Menu

Hold for 2 Seconds to open menu

Spin Wheel to navigate menu

Menu Guide



RETICLES

Remove or change your reticle to your liking



Library

See your photos and videos



Day/Night

Change your infrared settings for day or night observations



Sleep Mode

Use Sleep Mode to keep your OMNIS active and save battery life



Settings

Change your settings and set your own preferences



Range Finding Bracket

Use your OMNIS to spot your distances



Mode

Use the mode to select between Traditional and ballistic mode



Bullet Type

Change your Bullet Profile settings



Update

Update your Noctis V1

Batteries must be charged separately from unit



CHARGING READY